

Diffraction: Lab 4

6.2370 Modern Optics Project Laboratory
Daniel Sanango

Overview


Essentials



Experiment



Observations






Diffraction Essentials

1) Fourier Transform

- Spatial Domain
- Spatial Frequency Domain
- NOT Time



blogspot.com




Diffraction Essentials

2) Intensity

- What we visibly see
- $I \propto E^2$

3) Interference

- Causes “nulls”
- Related to phase
- Path length differences





Fraunhofer Far Field - Fourier Transform

$$\underline{U}_2(x_2, y_2) = \frac{1}{j\lambda z} e^{jkz} \int_{-\infty}^{\infty} \int_{-\infty}^{\infty} \underline{U}_1(x_1, y_1) e^{-j2\pi(f_x x_1 + f_y y_1)} dx_1 dy_1$$

Where,...

$\underline{U}_2(x_2, y_2) \rightarrow$ Diffracted Electric Field


$\frac{1}{j\lambda z} \rightarrow$ Scaling Factor

$e^{jkz} \rightarrow (+\hat{z})$ Wave Propagation

$\underline{U}_1(x_1, y_1) \rightarrow$ Input Electric Field


$e^{-j2\pi(f_x x_1 + f_y y_1)} \rightarrow (+\hat{x}_1)$ and $(+\hat{y}_1)$

Rect Function



University of Guelph

Sinc Function




University of Guelph

Most Common Transform Pair in this Lab:



Single Slit - Experiment



Objective:

- Find slit width relation to diffraction pattern

Setup:

- Variable slit device
- Red light


Approach:

- Make note of relation




Single Slit - Lab Experiment


Setup:



Results:



Large slit width



Small slit width




Single Slit - Observations

Observations:

- Matches theory


$$I(f_x) = K A^2 a^2 \left| \frac{\sin(\pi f_x a)}{\pi f_x a} \right|^2 |\delta(f_y)|^2$$

$$I(x_2) = I_0 \operatorname{sinc}^2(x_2 a / \lambda L)$$



Desmos

$\operatorname{sinc}(ax)$, a small




Desmos

$\operatorname{sinc}(ax)$, a large



Double Slit - Experiment



6.2370 Lecture Notes

Objective:

- Find slit width relation to diffraction pattern

Setup:

- Double slit grating with fixed grating distances (a, b)

Approach:


- Make note of relation



Double Slit - Lab Experiment

Notes about Slit

- Top numbers: “b” for top row
- Top Row: Huge “b”, Small “a”
- Bottom Row: Small “b”, Big “a”







Double Slit - Lab Experiment



↑a, ↓b (bottom)

↓a, ↑b (top)

↑b (right)





↓b (left)





Double Slit - Observations



6.2370 Lecture Notes

Observations:

[3] \rightarrow Largest a , Smallest b
greatest space range


[2] \rightarrow Smallest a , Largest b
greatest pattern density

[1] \rightarrow Similar to ([3]), b Larger

[4] \rightarrow Similar to ([2]), b Smaller



Numerous Slits - Experiment



6.2370 Lecture Notes

Objective:

Find slit width relation to diffraction pattern

Setup:



- Set slit mask
- Red light

Approach:

- Make note of relation




Numerous Slits - Lab Experiment




Observations:

- Have speckles
 - Implies aging
- More Lines \rightarrow More Spread





Rectangular Slit - Experiment



6.2370 Lecture Notes

Objective:

- Find slit width relation to diffraction pattern

Setup:



- Set slit grating
- Red light

Approach:

- Make note of relation



Rectangular Slit - Results



Observations:

- 1) Matches Theory
 - Basically a vertical and horizontal slit
 - With single slit, had ignored y-dimension
- 2) Similarities to slit
 - Rectangular center