

Polarization: Lab 2

6.2370 Modern Optics Project Laboratory

Daniel Sanango

Overview


Essentials




Experiment



Observations





E: Electric Field

H: Magnetic Field

k: Propagation Direction


Right hand Rule: $\text{direction}(k) = \text{direction}(E) \times \text{direction}(H)$



Plane of Incidence

When light strikes a medium

Contains normal vector and k-vector






Incidence with a Dielectric

3 components:

- Incident wave
- Reflected wave
- Transmitted wave

n: index of refraction

- Dependent on material properties
- Permittivity (ϵ)
- Permeability (μ)



Snell's Law :


$$n_1 \sin\theta_1 = n_2 \sin\theta_2$$




TE and TM Waves

“Transverse” \Rightarrow Out of Plane of Incidence

TE - Transverse Electric



TM - Transverse Magnetic






Polarization

Identified with E-field directionality

Polarizer:

- Polarization axis
- Light parallel to axis





Brewster's Angle

Reflected wave: result of dipole excitation

At the Brewster Angle...



TE: excites dipole

TM: does not excite dipole

Result:

- TE reflected
- TM disappears

Thus, reflection is TE







Waveplates

“Fast” and “slow” axis

- “Fast” keeps polarization
- “Slow” gets a phase delay






Total Internal Reflection

Light is completely reflected into original medium
No transmission

Snell's Law :

$$n_1 \sin\theta_1 = n_2 \sin\theta_2$$

Set transmitted angle to 90 degrees





Assignment: Axis of Polarizer

Objective:

Figure out polarization axis of a polarizer


Setup:

Floor wax

Polarizer with unknown polarizing axis

Approach:

“Shiny part” → Brewster’s Angle






Assignment: Axis of Polarizer

Results:

- Light is TE on plane of incidence
- If $TE \perp$ axis, no bright spot

Therefore, axis is where no floor shine is visible through polarizer



Result: No light!




Assignment: Mystery Waveplate

Objective:

- Given a half waveplate (HWP) and quarter waveplate (QWP), identify which is which
- Given “A” and “B” plates

Approach:

- Circularly polarized light: component in all directions
- Plates have no effect if polarized light does not hit both axes




Circularly-Polarized Light



Assignment: Mystery Waveplate

Setup In Lab:






Assignment: Mystery Waveplate

Results:

| (A) Null Angle | (B) Null Angle |
|----------------|----------------|
| 0° | 45° |
| 90° | 135° |
| 180° | 225° |
| 270° | 315° |






Assignment: Mystery Waveplate

Analysis:

Plates only polarize if two components on axis

Quarter wave: no circular at **red**

Half wave: no “flip” at **blue**





Assignment: Brewster Angle with Rotary Table

Setup:


- Light TM polarized
- Light incident with a piece of glass
- Photodetector measuring intensity

Known

- For TM, a certain angle will cause intensity to vanish

Objective

- Find Brewster's Angle





Assignment: Brewster Angle with Rotary Table

Results:

| Angle of Incidence (degrees) | Photodetector Reading [μW] |
|------------------------------|---|
| 10 | 23 |
| 20 | 22 |
| 30 | 23 |
| 40 | 19 |
| 50 | 18 |
| 60 | 22 |
| 70 | 38 |
| 80 | 87 |



Assignment: Brewster Angle with Rotary Table

Analysis:

- Lowest Intensity between 50 and 60 degrees
- Brewster angle between these angles
- Consistent with Brewster Angle of glass being 56 degrees






Assignment: Magic Sheet

Setup:

2 polarizers back-to-back

Objective:

Figure out what A and B are





Magic Sheet Approach

Solution:


Bend Sheets

“4 sheets” of polarization

From left to right, 2 cases:

BAAB

ABBA






Magic Sheet: BAAB



BAAB Alone



BAAB with a directional polarizer
in between

Observations:

- 1) No light ever comes through


Implications:

- 1) A must bend such that:

Axis of bent *orthogonal* to
axis of *original*



Magic Sheet: BAAB Conclusion



Conclusion:

- 1) A's Transmission axis 45 degrees from folding line

Reasoning:


After hitting A: completely polarized in one direction

Bend A: polarization axis orthogonal to original

No light in this direction!



Magic Sheet: ABBA



ABBA

Observations:


- 1) ~50% less light intensity

Implications:

- 1) The bend must not extinguish intensity
- 2) Should not cancel with B's established axes



Magic Sheet: ABBA Conclusion



Conclusion:

- 1) Transmission axis 90 degrees from folding line

Reasoning:

After hitting B: some intensity lost

Bent B: no change from B

Hitting A: intensity lost, but light still in B's transmission axis



Assignment: Total Internal Reflection


Objective:

- Find the critical angle of glass

Approach:

- Place glass on rotary table
- Place screen around area
- Rotate glass until only a beam from “transmitted” region is seen


Setup Schematic:






Assignment: Total Internal Reflection

Lab Setup:



Lab Results:



Analysis:

Looking at rotary table, critical angle is about 42 degrees

Consistent with known solution (42 degrees)

Closing Thoughts

Polarization useful for “filtering” light

Light reflection useful for fiber optics

Helpful to limit/expand parameters in lab setups